



#### HEADLIGHT HARNESS INSTALL INSTRUCTIONS

- A: Signal Connector *(to old bulb socket)*
- B: Integrated Fuse Holder
- C: 12v Power Lead *(to alternator)*
- D: Ground Lead *(to grounding lug on frame)*
- E: Passenger Side Bulb Socket
- F: Driver Side Bulb Socket

Disconnect negative connection from battery

Hook up 12v connection C to positive post on alternator

Hook up ground connection D to grounding lug on frame just under the driver's side headlight.

Unplug the original headlight connector from the driver's side headlight and plug signal connection A into this plug.

Plug headlight connector F into the driver's side headlight.

Rout the wire for headlight connector E along the path of the current wiring harness.

Plug headlight connector E into the passenger's side headlight.

Mount the two relays and fuse holder to the fender using self-drilling screws. A good place to do this is just below the coolant reservoir.

